

Handle (hex)	Type (hex)	Type (text)	Hex value	GATT Server Permissions	Description/Value (text)
0x0001	0x2800	GATT Primary Service Declaration	00:18	R	Generic Access Service
0x0002	0x2803	GATT Characteristic Declaration	02:03:00:00:2A	R	Device Name
0x0003	0x2A00	Device Name	74:61:73:6b:69:74:20:42:4c:45:32:33:32	R	"taskit BLE232"
0x0004	0x2803	GATT Characteristic Declaration	02:05:00:01:2A	R	Appearance
0x0005	0x2A01	Appearance	00:00	R	
0x0006	0x2803	GATT Characteristic Declaration	0A:07:00:02:2A	R	Peripheral Privacy Flag
0x0007	0x2A02	Peripheral Privacy Flag	00	RW	
0x0008	0x2803	GATT Characteristic Declaration	08:09:00:03:2A	R	Reconnection Address
0x0009	0x2A03	Reconnection Address		W	
0x000A	0x2803	GATT Characteristic Declaration	02:0B:00:04:2A	R	Peripheral Preferred Connection Parameters
0x000B	0x2A04	Peripheral Preferred Connection Parameters	50:00:A0:00:00:00:E8:03	R	P
0x000C	0x2800	GATT Primary Service Declaration	01:18	R	Generic Attribute Service
0x000D	0x2803	GATT Characteristic Declaration	20:0E:00:05:2A	R	Service Changed
0x000E	0x2A05	Service Changed			
0x000F	0x2902	Client Characteristic Configuration	00:00	RW	Write "01:00" to enable notifications, "00:00" to disable
0x0010	0x2800	GATT Primary Service Declaration	0A:18	R	Device Information Service
0x0011	0x2803	GATT Characteristic Declaration	02:12:00:23:2A	R	System ID
0x0012	0x2A23	System ID		R	
0x0013	0x2803	GATT Characteristic Declaration	02:14:00:24:2A	R	Serial Number String
0x0014	0x2A25	Serial Number String	4E:2E:41:2E:00	R	"N.A."
0x0015	0x2803	GATT Characteristic Declaration	02:16:00:25:2A	R	Firmware Revision String
0x0016	0x2A26	Firmware Revision String	31:2E:30:00	R	"1.0"
0x0017	0x2803	GATT Characteristic Declaration	02:18:00:26:2A	R	Hardware Revision String
0x0018	0x2A27	Hardware Revision String	41:2D:30:32:00	R	"A-02"
0x0019	0x2803	GATT Characteristic Declaration	02:1A:00:27:2A	R	Manufacturer Name String
0x001A	0x2A29	Manufacturer Name String	74:61:73:6b:69:74:20:47:6d:62:48:00	R	"taskit GmbH"
0x001B	0x2800	GATT Primary Service Declaration	1B:C5:D5:A5:02:00:60:A7:E3:11:4B:3D:F0:FF:2F:91	R	BLE232 Service
0x001C	0x2803	GATT Characteristic Declaration	18:1D:00:1B:C5:D5:A5:02:00:60:A7:E3:11:4B:3D:F1:FF:2F:91	R	BLE232 Serial Port Interface
0x001D	0xFFF1	BLE232 Interface		NW	
0x001E	0x2902	Client Characteristic Configuration	00:00	RW	Write "01:00" to enable notifications, "00:00" to disable
0x001F	0x2901	Characteristic User Description	53:65:72:69:61:6C:20:50:6F:72:74:20:49:6E:74:65:72:66:61:63:65	R	"Serial Port Interface"
0x0020	0x2803	GATT Characteristic Declaration	0A:21:00:1B:C5:D5:A5:02:00:60:A7:E3:11:4B:3D:F2:FF:2F:91	R	BLE232 Serial Port Config
0x0021	0xFFF2	BLE232 Config	04	R	
0x0022	0x2901	Characteristic User Description	53:65:72:69:61:6C:20:50:6F:72:74:20:43:6F:6E:66:69:67	R	"Serial Port Config"
0x0023	0x2803	GATT Characteristic Declaration	0A:24:00:1B:C5:D5:A5:02:00:60:A7:E3:11:4B:3D:F3:FF:2F:91	R	BLE232 Note
0x0024	0xFFF3	BLE232 Note		RW	
0x0025	0x2901	Characteristic User Description	4E:6F:74:65	R	"Note"
0x0026	0x2803	GATT Characteristic Declaration	0A:27:00:1B:C5:D5:A5:02:00:60:A7:E3:11:4B:3D:F4:FF:2F:91	R	BLE232 Device Name
0x0027	0xFFF4	BLE232 Device Name	74:61:73:6B:69:74:20:42:4C:45:32:33:32:00	RW	"taskit BLE232"
0x0028	0x2901	Characteristic User Description	42:4C:45:32:33:32:20:44:65:76:69:63:65:20:4E:61:6D:65	R	"BLE232 Device Name"